
Meridian 1

ISDN Basic Rate Interface

Maintenance

Document Number: 553-3901-500

Document Release: Standard 5.00

Date: October 1997

© 1992, 1997

All rights reserved

Printed in Canada

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Revision history

October 1997

Issue 5.00 released as Standard for Generic X11 Release 23.

August 1996

Issue 4.00 released as Standard for Generic X11 Release 22.0x.

December 1995

Issue 3.00 released as Standard for Generic X11 Release 21.1x.

July 1995

Issue 2.00 released as Standard for Generic X11 Release 21.0x.

December 1994

Issue 1.00 released as Standard for Generic X11 Release 20.

July 1994

Standard version issued for Generic X11 Release 20.

July 1993

Standard version issued, Phase 8.

Contents

About this guide	1
Applicability of this guide	1
How this guide is organized	2
Related documents	2
 Isolating and correcting faults	 3
Introduction	3
Fault detection and correction	3
Newly installed ISDN BRI equipment	4
Previously operating ISDN BRI equipment	4
Isolating faults	5
MISP fault isolation and correction	9
Checking the MISP status	10
Performing the MISP self-test	17
Performing the MISP loopback tests	18
Performing the ISDN BRI trunk remote loopback test	26
BRSC fault isolation and correction	29
Checking the BRSC status	29
Checking the status of the BRSC card identification and loadware versions	32
Checking the status of the Terminal Endpoint Identifiers	32
Performing the BRSC self-test	33
Performing the BRSC loopback tests	34
SILC or UILC fault isolation and correction	38
Checking the SILC or UILC status	38

Checking the DSL status	48
Performing the SILC or UILC self-test	52
MPH fault isolation and correction	54
Using the MPH loopback tests	55
ISDN BRI maintenance commands	62
MISP maintenance commands	62
BRSC maintenance commands	64
SILC and UILC maintenance commands	66
MPH maintenance commands	70
MISP and SILC/UILC message monitoring commands	73
Application download and enable application failure messages ...	76
Replacing ISDN BRI cards	77
Unpacking replacement cards	77
Removing and replacing the MISP	78
Removing and replacing the SILC, UILC or BRSC	82
Verifying operation	84
Reinstalling covers	84
Packing and shipping defective cards	85
Testing and troubleshooting ISDN BRI terminals	87
Verifying a new M5317T terminal installation	87
Verifying user operation	87
Troubleshooting the M5317T	88
Isolating switch problems	88
Clearing error codes	88
Restoring dial tone	89
Isolating faulty keys	89
Verifying a new M5209T terminal installation	90
Running a self-test	90
Running a panel test	91
Making a test voice call	92
Making a test data call	92
Assigning the test display language	92

Troubleshooting the M5209T	94
Power and cable connection problems	94
Problems with the set components	96
Troubleshooting displayed error messages	96
ISDN BRI maintenance messages	97
ISDN Basic Rate Interface messages (BRIxxx)	97
ISDN BRI trunking messages (BRITxxx)	112
Background signaling diagnostic messages (BSDxxx)	127
Software error monitor messages (BUGxxxx)	130
Equipment data dump messages (EDDxxx)	133
Error monitor messages (ERRxxxx)	133
Network link messages (LNKxxx)	134
Network and peripheral replacement messages (NPRxxx)	134
Network and signal diagnostic messages (NWSxxx)	136
MPH messages (MPHxxx)	138
Service change messages (SCHxxxx)	143
System loader messages (SYSxxxx)	156